

Troubleshooting: Brake Pad Backing Plate Rust

Problem

Brake pad backing plate is rusted



Likely Cause

- Backing plate coating was affected by high humidity or corrosive chemicals

Solutions

- Check if backing plate rust has affected pistons or other caliper parts
- Replace the corroded pads with pads featuring a better rustproofing
- Replace the caliper parts affected by rust