


## Troubleshooting: Brake Pad Brake Noise

### Problem

Squeal or squeak can be heard when brakes are applied



### Likely Cause

- Caliper piston is sticking
- Brake pad shims were not installed or installed improperly
- Pebbles and sand caught between pad & rotor
- PBC grease was not applied during brake pad installation

### Solutions

- Check caliper piston and piston seal for damage and rust
- Check if brake pads and shims are installed properly

- Check rotor surface for grooves
- Apply PBC grease