

## Troubleshooting: Car Judder When Brakes Are Applied

### Problem

A judder occurs when brakes are applied



### Likely Cause

- Uneven rotor wear due to caliper malfunction
- Uneven rotor thickness due to overheating
- Improper rotor installation
- Rotor surface partial rust

### Solutions

- Check rotor surface condition for any signs of deformation
- Check brake rotor for rust
- Check if brake rotor is properly installed
- Replace the rotor if necessary